

ICE PROTECTION SYSTEM

INSTRUMENT	FUNCTION
A	ENGINE ICE WARNING LIGHT (TO ICE DETECTORS ON NO'S 2 & 3 ENGINES)
B	OVER-PRESSURE WARNING LIGHT
C	MASTER SWITCH FOR ICE PROTECTION SYSTEM
D	ALTERNATE CYCLING VALVE TIMER SWITCH
E	SUPPLY AIR TEMP. INDICATOR: L.H. NACELLES (DUAL READING)
F	SUPPLY AIR TEMP. INDICATOR: R.H. NACELLES (DUAL READING)
G	ALTERNATE CYCLING VALVE TIMER AND DE-ICING SEGMENT INDICATOR
H	CYCLING VALVE TIMER AND DE-ICING SEGMENT INDICATOR
I	ICE PROTECTION FLOW INDICATOR: L.H. WING
J	ICE PROTECTION FLOW INDICATOR: R.H. WING
K	ICE PROTECTION FLOW INDICATOR: EMPENNAGE
L	CONTROL LEVERS FOR ENGINE BLEED SHUT-OFF VALVES

CONFIDENTIAL